Soft Start-up Valve AV2000-A/3000-A/4000-A/5000-A

Note) Manual override with locking

				How to Order	because th safety stand		comply wi	th	
V	3	000-F0	3 B	S-5DA- 9 9 9 9 9	X20	06		I	0
<u> </u>						Body size			
			Symbol	Description					
						20	30	40	50
			Nil	Rc					
	Thread type		Ν	NPT					
			F	G		\bullet	\bullet	\bullet	
			+ 02	1/4			1		
				3/8		-	•		$\pm \pm$
Port size			03	1/2			_	•	<u> </u>
			06	3/4			_	_	
			10	1		_	_	—	
			+			-		-	
	а	a Mounting	Nil	Without mounting option		•	•	•	
Option		-	B +	With bracket		•	•		
		_	Nil	Without pressure gauge					
	b Pressure gauge	G	Round type pressure gauge (with limit indicator	r)	•	•	•	Ŏ	
	+								
	c Silencer		Nil	Without silencer		•	•		
			S	Silencer (Built-in)					
			+ 5	24 VDC					
	Rated coil voltage			12 VDC		•			
			<u>6</u> +	12 000					
			G	Grommet (Lead wire length: 300 mm)					
				Type D (DIN terminal/With connector)		●	•	•	
Electrical entry			Y	Type Y (DIN terminal/With connector)*1					
			DO	Type D (DIN terminal/Without connector)			•		
			YO	Type Y (DIN terminal/Without connector)					
1		Light/	+ Nil	Without light/surge voltage suppressor					
	sur	ge voltage suppressor	Z	With light/surge voltage suppressor		 *2	*2	 *2	0*
			+						
8	d	Flow direction	Nil	Flow direction: Left to right					
Semi-standard	a	Flow direction	R	Flow direction: Right to left					
	_		+						
-i-u-		e Pressure unit	Nil	Name plate and pressure gauge: MPa					
Sei	е		Z *3	Name plate: psi Pressure gauge: MPa/psi dual scale		○*4	○*4	○*4	0*
			+						<u> </u>
		•• • ••	Nil	Non-locking push type					
9		Manual override		No manual override		•	•	•	
Whe For t	n the he pi	electrical entry is "DO" or " pe thread type: NPT	'YO," the I	EN-175301-803C (former DIN43650C). ght/surge voltage suppressor cannot be selected. g to the New Measurement Act. (The SI unit type is		semi-stan Option/Se	e each for o dard options mi-standard one specif	s " d " and " e I symbol: V	e." Vhen

provided for use in Japan.) *4 Pressure unit Z: For the pipe thread type: NPT only

indicate in alphabetical order.

Example) AV2000-02BGS-5D-A-X2006

U D